


REMOTE CONTROL INSTRUCTION MANUAL - AIRTIES



For more information, please call 101
or visit www.etisalat.ae/elife



Key	Basic Functions
1	Power Switch on and off
2	Radio Radio
3	1-9# Channel navigation
4	Menu Menu
5	EPG Display search/filter menu
6	Arrow Up Move selection up
	Arrow Down Move selection down
	Arrow Left Move selection left
	Arrow Right Move selection right
	OK OK/Enter
7	Back Exit or go back
8	Information Launch information/ extended information
9	Mute Mute the audio
10	Volume Up/Down Increase and decrease volume
11	Channel Up/down Surf channels
12	Play Playback
	Stop To stop playback. Return to live TV
	Rew To rewind/Page down (in case PVR functions are being used)
	FFW To fast forward/Page up
13	Pause To pause TV
14	Record To start recording

Additional functions

In Live TV, with info bar on display or within channel list, press up key to show the program details and PIP of the next channel.

In Live TV, with info bar on display or within channel list, press down key to show the program details and PIP of the previous channel.

In Live TV, with info bar on display, press left key to show the previous program details. With no info bar on display, press left key to zap to the last channel watched.

In Live TV, with info bar on display, press right key to show the next program details. With no info bar on display, press right key to display the channel list.

To delete any input into the text box

Return to Live TV (in case PVR functions are being used)