

# Audio/Amp Codes

(Khamsin RCU model)



Brand	Code
AIWA	0184
AIWA	0439
AIWA	0384
AIWA	0359
AIWA	0331
AIWA	0062
AIWA	0019
ALCO	0478
ALTEC LANSING	0442
ALTEC LANSING	0441
AMC	0155
AMW	0349
ANAM NATIONAL	0105
APEX	0094
APEX	0317
APEX DIGITAL	0094
APPLE	0103
ARCAM	0105
ARCAM	0443
AUDIOSOURCE	0445
AUDIOSOURCE	0444
AUDIOSOURCE	0137
AUDIOSOURCE	0015
AUDIOTRONIC	0105
AUVIO	0119
AVERMEDIA	0040

Brand	Code
B&W	0120
B&W	0428
B&W	0121
B&W	0274
BLACK WEB	0224
BLACK WEB	0270
BLACK WEB	0265
BLUESOUND	0508
BOHM	0446
BOMAKER	0501
BOSE	0109
BOSE	0073
BOSE	0074
BOSE	0447
BOSE	0398
BOSE	0355
BOSE	0272
BOSE	0183
BOSTON	0122
BOSTON ACOUSTICS	0408
BOSTON ACOUSTICS	0122
CAMBRIDGE	0276
CAMBRIDGE AUDIO	0448
CARVER	0292
CARVER	0105
CENTRIOS	0403

Brand	Code
CENTRIOS	0393
CENTRIOS	0392
CENTRIOS	0382
CENTRIOS	0370
CITIZEN	0303
CLASSIC	0405
COBY	0124
COBY	0123
CRAIG	0125
CREATIVE	0482
CRITERION	0344
DEFINITIVE TECHNOLOGY	0108
DEFINITIVE TECHNOLOGY	0081
DELPHI	0311
DENON	0234
DENON	0522
DENON	0521
DENON	0520
DENON	0519
DENON	0449
DENON	0410
DENON	0372
DENON	0367
DENON	0360
DENON	0307

Brand	Code
DENON	0252
DENON	0247
DENON	0246
DENON	0206
DENON	0197
DENON	0170
DENON	0156
DENON	0126
DENON	0087
DENON	0086
DENON	0085
DENON	0127
DURABRAND	0407
DURABRAND	0293
DYNEX	0281
DYNEX	0049
EDIFIER	0257
EGREAT	0493
EMERSON	0378
ENERGY	0514
ENERGY	0208
ENERGY	0134
ENERGY	0105
ETON	0025
FISHER	0279
FOCAL	0450
GOLDSTAR	0295
GOODMANS	0210
GOODMANS	0209
GOOGLE	0207
GPX	0128
GRUNDIG	0058
HAIER	0273
HARMAN/KARDON	0117
HARMAN/KARDON	0043
HARMAN/KARDON	0003
HARMAN/KARDON	0002
HARMAN/KARDON	0319
HARMAN/KARDON	0278
HARMAN/KARDON	0201

Brand	Code
HARMAN/KARDON	0165
HARMAN/KARDON	0151
HARMAN/KARDON	0004
HARMAN/KARDON	#VALUE!
HARMAN/KARDON	0129
HITACHI	0130
ILIVE	0110
ILIVE	0481
ILIVE	0480
ILIVE	0479
INNOVATIVE TECHNOLOGY	0138
INSIGNIA	0236
INSIGNIA	0049
INSIGNIA	0339
INSIGNIA	0205
INSIGNIA	0195
INSIGNIA	0193
INSIGNIA	0155
INSIGNIA	0153
INSIGNIA	0048
INTEGRA	0451
INTEGRA	0168
INTEGRA	0164
INTEGRA	0026
JAMO	0208
JBL	0151
JBL	0117
JBL	0146
JBL	0500
JBL	0260
JBL	0133
JBL	0132
JBL	0131
JENSEN	0488
JENSEN	0258
JNC	0056
JVC	0144
JVC	0150
JVC	0368
JVC	0337

Brand	Code
JVC	0289
JVC	0200
JVC	0175
JVC	0171
JWL	0371
KENWOOD	0020
KENWOOD	0396
KENWOOD	0364
KENWOOD	0333
KENWOOD	0325
KENWOOD	0318
KENWOOD	0298
KENWOOD	0181
KLH	0322
KLH	0275
KLIPSCH	0208
KLIPSCH	0221
KLIPSCH	0515
KLIPSCH	0291
KLIPSCH	0259
KLIPSCH	0222
KLIPSCH	0134
KLIPSCH	0105
KODA	0393
KOSS	0294
LENOXX	0386
LEON	0223
LEXICON	0492
LG	0231
LG	0054
LG	0061
LG	0453
LG	0452
LG	0395
LG	0389
LG	0293
LG	0198
LG	0163
LOGIK	0149
LOGITECH	0509

Brand	Code
MAGNAVOX	0383
MAGNAVOX	0366
MAGNAVOX	0305
MAGNAVOX	0296
MAGNAVOX	0279
MAGNAVOX	0177
MAGNAVOX	0159
MAGNAVOX	0115
MAGNAVOX	0112
MAGNAVOX	0105
MAGNAVOX	0047
MARANTZ	0089
MARANTZ	0021
MARANTZ	0454
MARANTZ	0320
MARANTZ	0280
MARANTZ	0162
MARANTZ	0159
MARANTZ	0105
MARANTZ	0090
MARANTZ	0440
MARANTZ	0102
MARANTZ	0101
MARANTZ	0100
MARANTZ	0099
MARANTZ	0098
MARANTZ	0097
MARTIN LOGAN	0456
MARTIN LOGAN	0455
MCLNTOSH	0162
MEMOREX	0036
MERIDIAN	0113
MICROMEGA	0105
MINT	0457
MITSUBISHI	0071
MYRON & DAVIS	0394
MYRYAD	0105
NAD	0091
NAD	0093
NAD	0039

Brand	Code
NAD	0038
NAD	0460
NAD	0459
NAD	0458
NAD	0365
NAD	0343
NAKAMICHI	0491
NELSON	0382
NEO	0284
NESA	0394
NEXXTECH	0382
NEXXTECH	0370
NEXXTECH	0356
NEXXTECH	0351
NEXXTECH	0339
NEXXTECH	0336
NEXXTECH	0330
NEXXTECH	0328
NEXXTECH	0324
NORCENT	0350
ONKYO	0217
ONKYO	0026
ONKYO	0235
ONKYO	0387
ONKYO	0363
ONKYO	0357
ONKYO	0348
ONKYO	0310
ONKYO	0286
ONKYO	0283
ONKYO	0178
ONKYO	0168
ONKYO	0088
ONKYO	0135
ONN	0226
ONN	0427
ONN	0271
ONN	0270
ONN	0269
ONN	0268

Brand	Code
ONN	0267
ONN	0266
ONN	0264
ONN	0228
ONN	0227
ONN	0225
ONN (ROKU)	0427
OPTIMUS	0326
OPTIMUS	0313
OPTIMUS	0312
OPTIMUS	0308
OPTIMUS	0277
ORBITSOUND	0136
OUTLAW	0461
OUTLAW	0513
OUTLAW	0462
PANASONIC	0425
PANASONIC	0179
PANASONIC	0044
PANASONIC	0429
PANASONIC	0064
PANASONIC	0426
PANASONIC	0418
PANASONIC	0417
PANASONIC	0438
PANASONIC	0437
PANASONIC	0436
PANASONIC	0435
PANASONIC	0434
PANASONIC	0433
PANASONIC	0432
PANASONIC	0431
PANASONIC	0430
PANASONIC	0416
PANASONIC	0354
PANASONIC	0346
PANASONIC	0424
PANASONIC	0423
PANASONIC	0422
PANASONIC	0421

Brand	Code
PANASONIC	0420
PANASONIC	0419
PARADIGM	0465
PARADIGM	0464
PARADIGM	0463
PBX	0094
PEERLESS	0229
PHILIPS	0112
PHILIPS	0082
PHILIPS	0047
PHILIPS	0046
PHILIPS	0023
PHILIPS	0022
PHILIPS	0507
PHILIPS	0506
PHILIPS	0505
PHILIPS	0494
PHILIPS	0483
PHILIPS	0413
PHILIPS	0412
PHILIPS	0411
PHILIPS	0383
PHILIPS	0379
PHILIPS	0366
PHILIPS	0300
PHILIPS	0279
PHILIPS	0204
PHILIPS	0199
PHILIPS	0159
PHILIPS	0158
PHILIPS	0116
PHILIPS	0105
PHILIPS	0021
PHILIPS	0409
PINNACLE	0466
PINNACLE	0077
PIONEER	0240
PIONEER	0230
PIONEER	0415
PIONEER	0363

Brand	Code
PIONEER	0353
PIONEER	0323
PIONEER	0315
PIONEER	0277
PIONEER	0244
PIONEER	0241
PIONEER	0239
PIONEER	0233
PIONEER	0174
PIONEER	0137
PIONEER	0095
PIONEER	0024
PIONEER	0018
POLAROID	0096
POLAROID	0059
POLK AUDIO	0115
POLK AUDIO	0196
POLK AUDIO	0162
POLK AUDIO	0035
POLK AUDIO	0078
PROFICIENT	0467
PROSCAN	0263
PROSCAN	0216
PROSCAN	0215
PROSCAN	0214
PROSCAN	0157
PROSCAN	0138
PYLE	0218
PYLE	0516
PYLE	0469
PYLE	0468
PYLE	0414
PYLE	0251
PYLE	0243
PYLE	0242
PYLE	0149
RADIO SHACK	0401
RADIO SHACK	0385
RADIO SHACK	0375
RADIO SHACK	0362

Brand	Code
RADIO SHACK	0327
RADIO SHACK	0323
RADIO SHACK	0301
RADIO SHACK	0299
RADIO SHACK	0297
RADIO SHACK	0291
RADIO SHACK	0285
RADIO SHACK	0277
RCA	0104
RCA	0139
RCA	0499
RCA	0478
RCA	0401
RCA	0385
RCA	0380
RCA	0375
RCA	0361
RCA	0352
RCA	0345
RCA	0340
RCA	0323
RCA	0309
RCA	0302
RCA	0291
RCA	0288
RCA	0203
RCA	0197
RCA	0192
RCA	0176
RCA	0157
RCA	0156
RCA	0105
REALISTIC	0358
REGENT	0386
RIF6	0511
RIO	0304
ROKU	0427
ROKU	0072
ROKU	0045
ROKU	0487

Brand	Code
RSR	0490
RSR	0489
SABA	0362
SAMSUNG	0005
SAMSUNG	0390
SAMSUNG	0190
SAMSUNG	0175
SAMSUNG	0165
SAMSUNG	0148
SAMSUNG	0114
SANSUI	0262
SANWO	0510
SANYO	0047
SANYO	0377
SANYO	0376
SANYO	0374
SANYO	0290
SANYO	0141
SANYO	0140
SCHIIT	0512
SCHIIT	0484
SCOTT	0314
SELECTRON	0406
SELECTRON	0404
SENNHEISER	0470
SHARP	0053
SHARP	0031
SHARP	0006
SHARP	0472
SHARP	0471
SHARP	0399
SHARP	0381
SHARP	0342
SHARP	0329
SHARP	0261
SHARP	0010
SHERWOOD	0236
SHERWOOD	0232
SHERWOOD	0193
SHERWOOD	0473

Brand	Code
SHERWOOD	0332
SHERWOOD	0299
SHERWOOD	0297
SHERWOOD	0237
SHERWOOD	0191
SHERWOOD	0155
SHERWOOD	0027
SHERWOOD	0193
NEWCASTLE	
SHINYBOW	0245
SHINYBOW	0250
SIRIUS	0052
SKYFI	0284
SONOS	0142
SONY	0180
SONY	0079
SONY	0145
SONY	0524
SONY	0388
SONY	0334
SONY	0316
SONY	0248
SONY	0219
SONY	0211
SONY	0194
SONY	0187
SONY	0186
SONY	0185
SONY	0182
SONY	0154
SONY	0041
SONY	0028
SONY	0016
SONY	0015
SPEAKERCRAFT	0467
SUNFIRE	0475
SUNFIRE	0474
SUPERSONIC	0476
TAO	0284
TAOTRONICS	0213
TCL	0213

Brand	Code
TCL	0212
TEAC	0105
TEAC	0306
TECHNICAL PRO	0249
TECHNICAL PRO	0238
TECHNICS	0438
TECHNICS	0436
TECHNICS	0435
TECHNICS	0431
TECHNICS	0346
TECHWOOD	0401
TECHWOOD	0397
TEVION	0344
THONET & VANDER	0485
THORENS	0105
TONGTEL	0063
TOSHIBA	0486
TOSHIBA	0143
TRUAUDIO	0477
ULTECH	0065
VENTURER	0478
VENTURER	0042
VINOIL	0502
VIZIO	0084
VIZIO	0147
VIZIO	0498
VIZIO	0402
VIZIO	0400
VMAI	0504
VMAI	0503
WOHOME	0497
WOHOME	0496
WOHOME	0495
XM RADIO	0311
XM RADIO	0284
YAMAHA	0106
YaMAHA	0068
YAMAHA	0066
YAMAHA	0050
YAMAHA	0523

Brand	Code
YAMAHA	0518
YAMAHA	0517
YAMAHA	0391
YAMAHA	0373
YAMAHA	0347
YAMAHA	0321
YAMAHA	0284
YAMAHA	0203
YAMAHA	0189
YAMAHA	0173

Brand	Code
YAMAHA	0172
YAMAHA	0169
YAMAHA	0161
YAMAHA	0152
YAMAHA	0111
YAMAHA	0107
YAMAHA	0055
YAMAHA	0067
ZENITH	0338
ZENITH	0335

Brand	Code
ZENITH	0326
ZENITH	0304
ZENITH	0295
ZENITH	0279
ZENITH	0163
ZUTEST	0255
ZUTEST	0254
ZUTEST	0253
ZVOX	0260

# TV Codes

(Kasai, Khamsin, Cool Click RCU models)

Brand	Code
ABEX	0323
ABEX	0198
ACCENT	0562
ACER	0470
ACER	0494
ACER	0176
ACME	0330
ADC	0401
ADC	0389
ADMIRAL	0318
ADVENT	0059
ADVENT	0394
ADVENT	0334
ADVENT	0225
AEG	0063
AFFINITY	0133
AFFINITY	0045
AFTRON	0161
AIKO	0562
AIKO	0503
AIKO	0359
AIM	0562
AIWA	0355
AIWA	0342
AIWA	0269
AKAI	0009
AKAI	0223
AKAI	0122
AKAI	0108
AKAI	0562
AKAI	0069
AKAI	0162
AKIBA	0562
AKISHI	0129
AKISHI	0077
AKITO	0562
AKURA	0562
ALBA	0562
ALIEN	0562

Brand	Code
ALLERON	0404
ALLSTAR	0562
AMSTRAD	0562
AMTRON	0430
AMW	0347
AMW	0339
ANAM NATIONAL	0562
ANAM NATIONAL	0439
ANAM NATIONAL	0430
ANAM NATIONAL	0427
ANAM NATIONAL	0416
ANAM NATIONAL	0315
ANAM NATIONAL	0138
ANITECH	0562
ANSONIC	0562
AOC	0188
AOC	0294
AOC	0231
AOC	0205
AOC	0084
AOC (ROKU TV)	0294
APEX	0027
APEX	0116
APEX	0463
APEX	0366
APEX	0360
APEX	0326
APEX	0313
APEX	0299
APEX	0085
APEX DIGITAL	0302
APEX DIGITAL	0027
APPLE TV	0535
APPLE TV	0115
ARDEM	0562
ARENA	0562
ARIO	0146
ARISTONA	0562
ASBERG	0562

Brand	Code
ASTRA	0562
ATLANTIC	0562
ATVIO	0127
ATVIO	0124
ATVIO	0294
ATVIO	0227
ATVIO	0208
ATVIO (ROKU TV)	0294
ATYME	0172
AUDIOSONIC	0562
AUDIOVOX	0559
AUDIOVOX	0506
AUDIOVOX	0497
AUDIOVOX	0496
AUDIOVOX	0430
AUDIOVOX	0369
AURIA	0205
AURIA	0084
AUTOVOX	0562
AUVIO	0155
AUVIO	0154
AVENTURA	0008
AVERA	0146
AVOL	0120
AVOL	0001
AVOL	0009
AWA	0001
AXESS	0272
AXION	0384
AXION	0352
BANG & OLUFSEN	0152
BANG & OLUFSEN	0002
BASIC LINE	0562
BAUR	0562
BBK	0118
BEKO	0562
BELL & HOWELL	0401
BELL & HOWELL	0380
BELL & HOWELL	0138

Brand	Code
BELSTAR	0562
BENQ	0489
BENQ	0406
BENQ	0078
BENQ	0431
BENQ	0407
BEON	0562
BESTAR	0562
BGH	0029
BLACK DIAMOND	0562
BLAUPUNKT	0144
BLOOM	0562
BLUE SKY	0562
BLUE SKY	0490
BLUE SKY	0476
BOE	0088
BOE	0188
BOLVA	0047
BOSE	0064
BPL	0562
BRINKMANN	0562
BRIONVEGA	0562
BROCKWOOD	0243
BROKSONIC	0400
BROKSONIC	0396
BROKSONIC	0353
BROKSONIC	0348
BROKSONIC	0312
BROKSONIC	0298
BROKSONIC	0141
BUSH	0562
BUSH	0067
BUSH	#VALUE!
Caixun	0550
CARAD	0562
CARENA	0562
CARREFOUR	0562
CASCADE	0562
CASIO	0562
CATHAY	0562

Brand	Code
CCE	0562
CCE	0484
CCE	0545
CCE	0130
CELERA	0028
CELERA	0085
CENTRIOS	0385
CENTURION	0562
CETOMER	0466
CETOMER	0215
CETRONIC	0416
CHALLENGER	0538
CHALLENGER	0001
CHANGHONG	0085
CHANGHONG	0068
CHANGHONG	0224
CHARTER COMMUNICATIONS	0309
CHIMEI	0062
CIELO	0136
CINERAL	0503
CINERAL	0476
CITIZEN	0430
CITIZEN	0416
CITIZEN	0386
CITIZEN	0359
CITIZEN	0137
CITIZEN	0079
CLARIVOX	0562
CLASSIC	0416
CLASSIC	0378
CLASSIC	0085
CLATRONIC	0562
CLP	0301
CLP CLASSIC	0243
CLP CLASSIC	0213
COBY	0061
COBY	0516
COBY	0474
COBY	0449
COBY	0448

Brand	Code
COBY	0447
COBY	0007
COLORTYME	0389
COMMERCIAL SOLUTIONS	0138
COMWAVE	0262
CONDOR	0562
CONRAD	0562
CONTEC	0562
CONTEC	0430
CONTEC	0416
CONTEC	0297
CONTEC	0246
CONTEX	0062
CORFUG	0070
CORNEA	0073
COSMEL	0562
CRAIG	0430
CRAIG	0416
CRAIG	0150
CRAIG	0062
CRAIG	0030
CROSLEY	0419
CROSLEY	0181
CROSLEY	0010
CROSSWOOD	0562
CROWN	0562
CROWN	0430
CROWN	0416
CRYSTAL	0027
CURTIS	0208
CURTIS	0148
CURTIS	0147
CURTIS	0146
CURTIS	0063
CURTIS	0062
CURTIS	0045
CURTIS	0009
CURTIS INTERNATIONAL	0149



Brand	Code
CURTIS INTERNATIONAL	0148
CURTIS INTERNATIONAL	0147
CURTIS INTERNATIONAL	0146
CURTIS INTERNATIONAL	0133
CURTIS INTERNATIONAL	0063
CURTIS INTERNATIONAL	0045
CURTIS MATHES	0079
CURTIS MATHES	0080
CURTIS MATHES	0395
CURTIS MATHES	0380
CURTIS MATHES	0314
CURTIS MATHES	0138
CURTIS MATHES	0137
CYBERVISION	0476
DAEWOO	0511
DAEWOO	0562
DAEWOO	0429
DAEWOO	0416
DAEWOO	0377
DAEWOO	0363
DAEWOO	0359
DAEWOO	0341
DAEWOO	0231
DAEWOO	0130
DAEWOO	0129
DAEWOO	0077
DANSAI	0562
DAWA	0562
DAYTRON	0562
DCE	0562
DECCA	0562
DELL	0487
DELL	0473
DELL	0387
DELL	0356
DELTON	0562

Brand	Code
DENVER	0562
DESMET	0562
DÉVANT	0178
DIAMANT	0562
DIAMOND VISION	0422
DIAMOND VISION	0399
DIAMOND VISION	0349
DIAMOND VISION	0325
DIGIHOME	0562
DIGIHOME	#VALUE!
DIGILINE	0562
DIGILOGIC	0562
DIGIMATE	0502
DIGISTAR	0021
DIGISTAR	0487
DIGISTAR	0334
DIGISTAR	0077
DIGITAL	0070
DIGITAL	0066
DIGITOR	0004
DIK	0562
DIRECTV	0079
DISTAR	0076
DIXI	0562
DMTECH	0192
DMTECH	0562
DOPPIO	0549
DSE	0063
DSE	0003
DSE	0001
DUAL	0562
DUKANE	0203
DUKANE	0198
DURABRAND	0083
DURABRAND	0562
DURABRAND	0386
DURABRAND	0311
DURABRAND	0141
DURABRAND	0073
DURABRAND	0028

Brand	Code
DURABRAND	0008
DUX	0562
D-VISION	0562
DYNASTY	0416
DYNATRON	0562
DYNEX	0225
DYNEX	0187
DYNEX	0186
DYNEX	0185
DYNEX	0184
DYNEX	0183
DYNEX	0182
DYNEX	0181
DYNEX	0180
DYNEX	0143
DYNEX	0093
DYNEX	0083
DYNEX	0036
DYNEX	0008
ELBE	0562
ELECTRO	0414
ELECTRO	0297
ELECTRON	0148
ELEKTA	0562
ELEKTA	0066
ELEKTRA	0126
ELEKTRA	0401
ELEMENT	0047
ELEMENT	0145
ELEMENT	0057
ELEMENT	0294
ELEMENT	0226
ELEMENT	0062
ELEMENT (ROKU TV)	0294
ELG	0562
ELIN	0562
ELITE	0562
ELITE VIDEO	0354
EMERSON	0135
EMERSON	0145

Brand	Code
EMERSON	0562
EMERSON	0363
EMERSON	0328
EMERSON	0324
EMERSON	0512
EMERSON	0430
EMERSON	0404
EMERSON	0380
EMERSON	0355
EMERSON	0348
EMERSON	0327
EMERSON	0306
EMERSON	0269
EMERSON	0008
ENGEL	0194
ENVISION	0205
ENVISION	0188
ENVISION	0101
ENVISION	0084
EQD	0205
EQD	0084
ERRES	0562
ESA	0386
ESA	0143
ESA	0008
ESC	0562
ETRON	0562
EUROMAN	0562
EUROPA	0562
EUROPHON	0562
EUROSKY	0562
EXCEL	0562
EXQUISIT	0562
F&U	0138
FAVI	0009
FERGUSON	0562
FFALCON	0211
FFALCON	0138
FFALCON	0086
FIDELITY	0562

Brand	Code
FINLUX	0562
FIRSTLINE	0562
FISHER	0405
FISHER	0380
FISHER	0235
FLINT	0562
FLUID	0442
FORMENTI	0562
FRABA	0562
FRIAC	0562
FUJICOM	0044
FUJITSU	0562
FUJITSU	0504
FUJITSU	0404
FUNAI	0008
FUNAI	0562
FUNAI	0404
FUNAI	0355
FUNAI	0324
FUNAI	0143
FUNAI	0135
FUNAI	0328
FUNAI	0269
FUNAI	0430
FUNAI	0416
FURRION	0212
FURRION	0044
FUSION	0088
FUTURETEC	0430
FUTURETEC	0416
GALAXIS	0562
GATEWAY	0204
GATEWAY	0104
GE (GENERAL ELECTRIC)	0075
GE (GENERAL ELECTRIC)	0515
GE (GENERAL ELECTRIC)	0418
GE (GENERAL ELECTRIC)	0351

Brand	Code
GE (GENERAL ELECTRIC)	0300
GE (GENERAL ELECTRIC)	0085
GE (GENERAL ELECTRIC)	0073
GEC	0562
GENERAL INSTRUMENT	0372
GENEXXA	0562
GFM	0143
GFM	0142
GFM	0135
GFM	0008
GIBRALTER	0357
GIBRALTER	0128
GLOBALSTAR	0548
GO VIDEO	0453
GOLDI	0088
GOLDSTAR	0562
GOLDSTAR	0355
GOLDSTAR	0269
GOLDSTAR	0231
GOLDSTAR	0073
GOODMANS	0562
GPX	0306
GPX	0169
GPX	0151
GPX	0168
GPX	0167
GPX	0166
GPX	0165
GPX	0164
GPX	0163
GRADIENTE	0562
GRADIENTE	0492
GRADIENTE	0491
GRADIENTE	0483
GRADIENTE	0436
GRADIENTE	0243
GRAETZ	0562

Brand	Code
GRANADA	0562
GRANDIN	0562
GRUNDIG	0247
GRUNDIG	0562
GUESTVISION	0413
GVISION	0514
H&B	0023
HAIER	0294
HAIER	0227
HAIER	0098
HAIER	0014
HAIER	0513
HAIER	0073
HAIER	0009
HAIER	0406
HAIER	0024
HAIER (ROKU TV)	0294
HALLMARK	0073
HANNSPREE	0042
HANNSPREE	0040
HANSEATIC	0562
HANTAREX	0562
HANTOR	0562
HARWOOD	0562
HAUPPAUGE	0562
HAUPPAUGE	0486
HAUPPAUGE	0053
HAVERMY	0139
HCM	0562
HEDZON	0562
HELLO KITTY	0519
HIGHLINE	0562
HINARI	0562
HISENSE	0145
HISENSE	0294
HISENSE	0228
HISENSE	0295
HISENSE	0196
HISENSE	0178
HISENSE	0009

Brand	Code
HISENSE (ROKU TV)	0294
HISENSE (ROKU TV)	0295
HITACHI	0203
HITACHI	0060
HITACHI	0562
HITACHI	0557
HITACHI	0528
HITACHI	0294
HITACHI	0269
HITACHI	0392
HITACHI	0365
HITACHI	0355
HITACHI	0198
HITACHI (ROKU TV)	0294
HITECH	0005
HKC	0044
HKPRO	0085
HÖHER	0562
HP(HEWLETT PACKARD)	0475
HP(HEWLETT PACKARD)	0072
HYPSON	0562
HYUNDAI	0549
HYUNDAI	0510
HYUNDAI	0265
IBERIA	0562
ICE	0562
ICT	0562
IKON	0170
ILO	0469
ILO	0420
ILO	0417
ILO	0386
ILO	0370
ILO	0223
ILO	0202
IMPERIAL	0562
INDIANA	0562
INFINITY	0419
INFINITY	0337

Brand	Code
INFOCUS	0153
INFOCUS	0138
INITIAL	0455
INITIAL	0417
INITIAL	0358
INNO HIT	0562
INNOVATION	0562
INSIGNIA	0225
INSIGNIA	0186
INSIGNIA	0143
INSIGNIA	0458
INSIGNIA	0185
INSIGNIA	0434
INSIGNIA	0093
INSIGNIA	0296
INSIGNIA	0294
INSIGNIA	0284
INSIGNIA	0187
INSIGNIA	0464
INSIGNIA	0328
INSIGNIA	0316
INSIGNIA	0036
INSIGNIA	0083
INSIGNIA	0183
INSIGNIA	0181
INSIGNIA	0182
INSIGNIA	0180
INSIGNIA	0014
INSIGNIA	0008
INSIGNIA (ROKU TV)	0294
INSIGNIA (ROKU TV)	0296
INTEC	0256
INTEQ	0357
INTEQ	0128
INTER	0157
INTERACTIVE	0562
INTERBUY	0562
INTERFUNK	0562
INTERNAL	0562
INTERVISION	0562

Brand	Code
IRRADIO	0562
ISUKAI	0562
ISYMPHONY	0009
ITS	0562
ITV	0562
JBL	0419
JC PENNEY	0418
JC PENNEY	0391
JC PENNEY	0300
JC PENNEY	0231
JC PENNEY	0138
JC PENNEY	0137
JC PENNEY	0079
JENSEN	0434
JMB	0562
JOCEL	0001
JVC	0230
JVC	0229
JVC	0009
JVC	0044
JVC	0402
JVC	0392
JVC	0331
JVC	0294
JVC (ROKU TV)	0294
JWF	0055
KAISUI	0562
KALLEY	0549
KALLEY	0265
KALLEY	0075
KALLEY	0001
KANJI	0044
KARCHER	0562
KATHREIN	0562
KAWASAKI	0321
KAWASHO	0414
KC	0117
KDS	0062
KEC	0416
KENDO	0562

Brand	Code
KENNEX	0562
KITON	0562
KLH	0085
KLOSS NOVABEAM	0308
KNEISSEL	0562
KNOLL	0039
SYSTEMS(ZENITH)	
KNOLL	0128
SYSTEMS(ZENITH)	
KOGAN	0079
KOGI	0514
KOLSTER	0562
KONKA	0562
KONKA	0388
KONKA	0265
KONKA	0036
KONKA	0507
KONKA	0430
KONKA	0224
KONKA	0049
KONKA	0043
KONKA	0025
KORPEL	0562
KOSMOS	0562
KREISEN	0029
KTC	0256
KTV	0041
KTV	0430
KTV	0416
KTV	0393
KTV	0297
KURAZAI	0401
KWORLD	0465
LASONIC	0399
LASONIC	0349
LAVIS	0562
LEADER	0087
LECSON	0562
LEEGE	0110
LEGEND	0334
LEGEND	0146

Brand	Code
LENCO	0562
LENOVO	0097
LENSON	0006
LETV	0540
LETV	0539
LEVIS AUSTRIA	0562
LEYCO	0562
LG	0014
LG	0190
LG	0156
LG	0562
LG	0277
LG	0257
LG	0206
LG	0073
LG	0372
LG	0365
LG	0355
LG	0231
LG	0138
LG	0269
LIFETEC	0562
LIQUIDVIDEO	0384
LIQUIDVIDEO	0367
LIQUIDVIDEO	0352
LODGENET	0499
LODGENET	0425
LODGENET	0401
LODGENET	0138
LOEWE	0114
LOEWE	0562
LOEWE	0419
LOGIK	0159
LOGIK	0138
LUCE	0317
LUMA	0562
LUMATRON	0562
LUX MAY	0562
LXI	0419
LXI	0380

Brand	Code
LXI	0355
LXI	0346
LXI	0314
LXI	0138
LXI	0079
LXI	0073
MADISON	0562
MAG	0062
MAGNASONIC	0404
MAGNAVOX	0019
MAGNAVOX	0016
MAGNAVOX	0562
MAGNAVOX	0509
MAGNAVOX	0337
MAGNAVOX	0328
MAGNAVOX	0324
MAGNAVOX	0318
MAGNAVOX	0294
MAGNAVOX	0143
MAGNAVOX	0101
MAGNAVOX	0008
MAGNAVOX (ROKU TV)	0294
MAGNUM	0562
MAJESTIC	0138
MANESTH	0562
MANHATTAN	0562
MARANTZ	0562
MARANTZ	0419
MARANTZ	0412
MARANTZ	0019
MARK	0562
MASTER-G	0265
MASTERTECH	0549
MATSUI	0562
MATSUSHITA	0524
MAXENT	0472
MAXENT	0104
MEDIATOR	0562
MEDION	0562
MEDION	0441

Brand	Code
MEDION	0370
MEDION	0364
MEGATRON	0203
MEGATRON	0073
MEI	0562
MEI	0297
MELECTRONIC	0562
MELODY	0086
MEMOREX	0017
MEMOREX	0073
MEMOREX	0404
MEMOREX	0380
MEMOREX	0312
MEMOREX	0298
MEMOREX	0270
MEMOREX	0225
MEMOREX	0138
MEMOREX	0087
MEMOREX	0014
MERCURY	0562
METZ	0562
MGA	0415
MGA	0409
MGA	0404
MGA	0246
MGA	0231
MGA	0073
MI	0536
MICROMAXX	0562
MIDLAND	0495
MIDLAND	0357
MIDLAND	0346
MIDLAND	0314
MIDLAND	0300
MIDLAND	0138
MIDLAND	0128
MINATO	0562
MINOKA	0562
MINOKA	0054
MINTEK	0035

Brand	Code
MINUTZ	0418
MISAKAI	0386
mitsubishi	0243
mitsubishi	0242
mitsubishi	0231
mitsubishi	0124
mitsubishi	0077
mitsubishi	0411
mitsubishi	0562
mitsubishi	0404
mitsubishi	0365
MITSUI	0243
MITSUI	0242
MITSUI	0124
MITSUI	0077
MITSUI	0523
MITSUI	0131
MITSUI	0129
MITSUI	0096
MITSUI	0095
MITSUI	0094
MITSUI	0093
MITSUI	0092
MITSUI	0091
MITSUI	0089
MITSUI	0030
MITSUI	0027
MITSUI	0005
MONIVISION	0332
MONTGOMERY WARD	0401
MONTGOMERY WARD	0138
MORAVA	0562
MOTEVA	0483
MOTEVA	0380
MOTOROLA	0451
MTC	0297
MTC	0231
MTC	0137
MTC	0079

Brand	Code
MULTILASER	0556
MULTITECH	0562
MUSIKLAND	0562
MYRON & DAVIS	0426
MYRYAD	0562
NAD	0562
NAD	0198
NAD	0079
NAD	0073
NAIKO	0562
NAOKI	0131
NAOKI	0091
NAOKI	0077
NAXA	0037
NAXA	0149
NAXA	0144
NAXA	0009
NEC	0134
NEC	0412
NEC	0322
NEC	0231
NEC	0082
NEC	0010
NET TV	0304
NET TV	0104
NEUFUNK	0562
NEXUS	0541
NEXUS	0184
NEXUS	0145
NEXXTECH	0375
NEXXTECH	0350
NIKAI	0076
NIKKEI	0416
NIKKO	0359
NIKKO	0073
NIKO	0479
NOBEL	0086
NOBLEX	0549
NOBLEX	0547
NOBLEX	0235

Brand	Code
NOBLEX	0145
NOBLEX	0546
NOBLEX	0224
NORCENT	0429
NORCENT	0188
NORCENT	0101
NPG	#VALUE!
NTC	0503
NTC	0359
NUVISION	0542
OBONI	0085
OBONI	0069
ÖLEVIA	0058
ÖLEVIA	0081
ONCOMMAND	0493
ONCOMMAND	0413
ONN	0086
ONN	0294
ONN	0263
ONN	0259
ONN (ROKU TV)	0294
ONWA	0430
ONWA	0416
OPTIMUS	0526
OPTIMUS	0524
OPTOMA	0443
OPTONICA	0390
OPTONICA	0322
ORION	0123
ORION	0562
ORION	0357
ORION	0141
ORION	0056
PACIFIC	0562
PALSONIC	0074
PANASONIC	0274
PANASONIC	0197
PANASONIC	0562
PANASONIC	0531
PANASONIC	0522

Brand	Code
PANASONIC	0456
PANASONIC	0140
PANAVOX	0549
PANDA	0063
PARK	0144
PEERLESS	0271
PENNEY	0073
PHILCO	0438
PHILCO	0265
PHILCO	0231
PHILCO	0143
PHILCO	0049
PHILCO	0132
PHILCO	0005
PHILIPS	0195
PHILIPS	0527
PHILIPS	0175
PHILIPS	0016
PHILIPS	0019
PHILIPS	0562
PHILIPS	0294
PHILIPS	0013
PHILIPS	0328
PHILIPS	0324
PHILIPS	0202
PHILIPS	0533
PHILIPS	0365
PHILIPS (ROKU TV)	0294
PHILIPS-MAGNAVOX	0480
PHILIPS-MAGNAVOX	0419
PHILIPS-MAGNAVOX	0019
PHILIPS-MAGNAVOX	0337
PHILIPS-MAGNAVOX	0318
PIONEER	0113
PIONEER	0323
PIONEER	0207
PIONEER	0534
PIONEER	0412
PIONEER	0376
PIVA	0410

Brand	Code
PIXEL	0012
PLANAR	0501
PLANAR	0188
POLAROID	0088
POLAROID	0119
POLAROID	0146
POLAROID	0508
POLAROID	0485
POLAROID	0280
POLAROID	0085
POLAROID	0079
POLAROID	0062
POLAROID	0053
POLAROID	0024
PORTLAND	0359
PORTLAND	0231
PRECISION	0336
PRIMA	0025
PRIMA	0334
PRIMA	0265
PRIMIER	0549
PRINCETON GRAPHICS	0390
PRINCETON GRAPHICS	0382
PRISM	0287
PROLINE	0562
PROMAC	0177
PROSCAN	0044
PROSCAN	0009
PROSCAN	0145
PROSCAN	0549
PROSCAN	0171
PROSCAN	0133
PROSCAN	0117
PROSCAN	0062
PROSCAN	0047
PROSCAN	0046
PROSCAN	0045
PROSCAN	0138
PROSCAN	0208

Brand	Code
PROSCAN	0437
PROSCAN	0423
PROSCAN	0314
PROSCAN	0210
PROSCAN	0200
PROSCAN	0016
PROTECH	0562
PROTON	0073
PROTRON	0502
PROTRON	0033
PROVIEW	0062
PULSAR	0357
PULSAR	0128
PYLE	0056
PYLE HOME	0056
QFX	0272
QUADRO	0562
QUASAR	0549
QUASAR	0532
QUASAR	0530
QUASAR	0526
QUASAR	0524
QUASAR	0522
QUASAR	0419
QUASAR	0300
RADIO SHACK	0515
RADIO SHACK	0430
RADIO SHACK	0403
RADIO SHACK	0380
RADIO SHACK	0355
RADIO SHACK	0322
RADIO SHACK	0246
RADIO SHACK	0138
RADIO SHACK	0073
RADIOTONE	0562
RCA	0233
RCA	0172
RCA	0260
RCA	0557
RCA	0544

Brand	Code
RCA	0528
RCA	0294
RCA	0290
RCA	0261
RCA	0232
RCA	0199
RCA	0198
RCA	0173
RCA	0145
RCA	0139
RCA	0130
RCA	0046
RCA	0045
RCA	0014
RCA	0009
RCA	0432
RCA	0206
RCA (ROKU TV)	0294
REALISTIC	0430
REALISTIC	0416
REALISTIC	0380
REALISTIC	0355
REALISTIC	0322
REALISTIC	0307
REALISTIC	0274
REALISTIC	0138
REALISTIC	0073
REVOLUTION HD	0038
RIVIERA	0079
RIVIERA	0085
ROADSTAR	0562
ROKU TV	0294
ROWA	0022
ROWA	0074
RUNCO	0412
RUNCO	0357
RUNCO	0128
SABA	0562
SALORA	0562
SAMPO	0104

Brand	Code
SAMSUNG	0009
SAMSUNG	0397
SAMSUNG	0562
SAMSUNG	0478
SAMSUNG	0471
SAMSUNG	0424
SAMSUNG	0395
SAMSUNG	0015
SAMSUNG	0466
SAMSUNG	0231
SAMSUNG	0079
SAMSUNG	0010
SAMTRON	0137
SANKEY	0044
SANSUI	0083
SANSUI	0062
SANSUI	0008
SANSUI	0400
SANSUI	0312
SANYO	0235
SANYO	0562
SANYO	0518
SANYO	0517
SANYO	0405
SANYO	0294
SANYO	0234
SANYO	0121
SANYO	0111
SANYO (ROKU TV)	0294
SCEPTRE	0032
SCEPTRE	0117
SCEPTRE	0031
SCEPTRE	0558
SCEPTRE	0477
SCEPTRE	0279
SCEPTRE	0010
SCHNEIDER	0562
SCOTCH	0073
SCOTT	0430
SCOTT	0416

Brand	Code
SCOTT	0404
SCOTT	0223
SCOTT	0073
SEALOC	0560
SEARS	0419
SEARS	0404
SEARS	0386
SEARS	0381
SEARS	0328
SEARS	0324
SEARS	0312
SEARS	0235
SEARS	0138
SEARS	0137
SEARS	0100
SEARS	0079
SEARS	0073
SEDEA	0193
SEG	0562
SEIKI	0047
SEIKI	0520
SEIKI	0079
SEIKI	0073
SEIKI	0057
SELECO	0562
SELECTRON	0446
SELECTRON	0445
SELECTRON	0444
SEMP	0481
SÉURA	0251
SHARP	0145
SHARP	0254
SHARP	0251
SHARP	0220
SHARP	0219
SHARP	0018
SHARP	0295
SHARP	0294
SHARP	0433
SHARP(ROKU TV)	0294

Brand	Code
SHARP(ROKU TV)	0295
SHARP(ROKU TV)	0220
SHENG-CHIA	0139
SHIVAKI	0562
SIGMAC	0150
SIGNATURE	0138
SIGNET	0461
SIGNET	0459
SIGNET	0457
SILO DIGITAL	0117
SILVERCREST	0562
SIMPLY	0119
SINUDYNE	0070
SIRAGON	0174
SKYVUE	0014
SKYWORTH	0238
SKYWORTH	0034
SKYWORTH	0191
SKYWORTH	0001
SKYWORTH	0237
SKYWORTH	0236
SOAIY	0158
SONIC	0297
SONIQ	0065
SONY	0561
SONY	0273
SONY	0010
SONY	0160
SOULACA	0282
SOUNDESIGN	0430
SOUNDESIGN	0416
SOUNDESIGN	0404
SOUNDESIGN	0073
SOVA	0505
SOVA	0482
SOYO	0036
SPECTRA	0399
SPECTRAVISION	0440
SPECTRONIQ	0033
SPELER	0125



Brand	Code
SQUAREVIEW	0386
SQUAREVIEW	0008
STAR SAT	0258
STARLITE	0430
SUMEC	0552
SUNBRITETV	0117
SUNBRITETV	0031
SUNBRITETV	0010
SUNBRITETV	0058
SUNBRITETV	0278
SUNSTECH	0063
SUPER GENERAL	0076
SUPERSCAN	0328
SUPERSCAN	0324
SUPERSONIC	0551
SUPERSONIC	0306
SUPERSONIC	0287
SUPERSONIC	0272
SUPERSONIC	0144
SUPERSONIC	0062
SUPRA	0421
SUPRA	0243
SUPRA	0070
SUPRA	0068
SVA	0143
SYLVANIA	0135
SYLVANIA	0324
SYLVANIA	0143
SYLVANIA	0355
SYLVANIA	0419
SYLVANIA	0328
SYLVANIA	0269
SYLVANIA	0209
SYLVANIA	0141
SYLVANIA	0008
SYMPHONIC	0430
SYMPHONIC	0386
SYMPHONIC	0355
SYMPHONIC	0328
SYMPHONIC	0324

Brand	Code
SYMPHONIC	0269
SYMPHONIC	0202
SYMPHONIC	0008
SYNTAX	0026
TATUNG	0406
TATUNG	0370
TATUNG	0204
TCL	0086
TCL	0294
TCL	0244
TCL	0557
TCL	0549
TCL	0528
TCL	0250
TCL	0249
TCL	0245
TCL	0222
TCL	0211
TCL	0138
TCL (ROKU TV)	0294
TECHLINE	0562
TECHNICAL	0562
TECHNICOLOR	0261
TECHNICS	0524
TECHNICS	0300
TECHWOOD	0562
TECHWOOD	0300
TECNISON	0562
TEKNIKA	0416
TEKNIKA	0404
TEKNIKA	0359
TEKNIKA	0308
TEKNIKA	0274
TEKNIKA	0231
TEKNIKA	0138
TEKNIKA	0137
TEKNIKA	0079
TELEFUNKEN	0137
TELERENT	0401
TELERENT	0138

Brand	Code
TELETECH	0562
TENSAI	0562
TERA	0338
TERA	0243
TESLA	0562
TEVION	0562
TEVION	0370
THOMSON	0086
THOMSON	0250
THOMSON	0249
THOMSON	0211
THTF	0112
THTF	0057
TMK	0073
TNCI	0128
TOPLINE	0562
TOSHIBA	0079
TOSHIBA	0248
TOSHIBA	0239
TOSHIBA	0240
TOSHIBA	0562
TOSHIBA	0395
TOSHIBA	0312
TOSHIBA	0303
TOSHIBA	0291
TOSHIBA	0286
TOSHIBA	0284
TOSHIBA	0298
TOSHIBA	0468
TOSHIBA	0412
TOSHIBA	0380
TOSHIBA	0372
TOSHIBA	0322
TRUTECH	0488
TRUTECH	0062
TRUTECH	0008
TVA	0255
TVS	0141
UNIVERSAL	0418
UNIVERSAL	0344

Brand	Code
UNIVERSUM	0562
UPSTAR	0189
UPSTAR	0179
VDIGI	0172
VENTURER	0486
VENTURER	0373
VESTEL	0562
VESTEL	#VALUE!
VICTOR	0500
VICTOR	0392
VIDEOCON	0498
VIDEOTON	0562
VIDTECH	0231
VIDTECH	0073
VIEWSONIC	0241
VIEWSONIC	0107
VIEWSONIC	0106
VIEWSONIC	0105
VIEWSONIC	0104
VIEWSONIC	0103
VIEWSONIC	0102
VIEWSONIC	0101
VIEWSONIC	0100
VIEWSONIC	0099
VIEWSONIC	0048
VIEWSONIC	0555
VIEWSONIC	0205
VIEWSONIC	0198
VIEWSONIC	0084
VIMAX	0109
VINCHI	0554
VIORE	0009
VIORE	0144
VIORE	0063
VIORE	0460
VISION QUEST	0543
VISION QUEST	0062
VIVAX	0138
VIVITEK	0537

Brand	Code
VIZIO	0221
VIZIO	0218
VIZIO	0215
VIZIO	0204
VIZIO	0102
VIZIO	0100
WALKER	0562
WALTON	0001
WARDS	0419
WARDS	0418
WARDS	0404
WARDS	0383
WARDS	0322
WARDS	0320
WARDS	0231
WARDS	0138
WARDS	0128
WARDS	0073
WATSON	0562
WAYCON	0140
WBOX	0529
WBOX	0256
WBOX	0087
WESTINGHOUSE	0294
WESTINGHOUSE	0010
WESTINGHOUSE	0117
WESTINGHOUSE	0435
WESTINGHOUSE	0302
WESTINGHOUSE	0268
WESTINGHOUSE	0146
WESTINGHOUSE	0047
WESTINGHOUSE	0009
WESTINGHOUSE	0462
WESTINGHOUSE	0294
WESTINGHOUSE (ROKU TV)	
WHITE-WESTINGHOUSE	0355
WHITE-WESTINGHOUSE	0343

Brand	Code
WHITE-WESTINGHOUSE	0335
WHITE-WESTINGHOUSE	0269
WHITE-WESTINGHOUSE	0141
WHITE-WESTINGHOUSE	0130
WILSON	0562
WINDSOR	0562
WYSE	0101
XIAOMI	0536
XMS	0074
XOCECO	0050
XOCECO	0051
XOCECO	0025
XOCECO	0071
XOCECO	0020
XTRATECH	0191
YAMAHA	0274
YAMAHA	0231
ZENITH	0408
ZENITH	0512
ZENITH	0503
ZENITH	0428
ZENITH	0400
ZENITH	0395
ZENITH	0379
ZENITH	0361
ZENITH	0357
ZENITH	0355
ZENITH	0337
ZENITH	0301
ZENITH	0269
ZENITH	0229
ZENITH	0014
ZENITH	0374
ZENITH	0318
ZUTEST	0283